

























Installation Manual for Manual Pergola 100B-4T



Item No.	Pic.		Qty.
A			1
B			1
C			1
D			1
E			3
T	 Marked "E" if not energized, without this plug		1
P			4





Item No.	Pic.		Qty.
I		3*3M	18
		3*4M	25
Q			4
R			1
N			1
		M4×10	
O			1
K/L	 No adaptor at both ends if no light		2
U/V	 No adaptor at both ends if no light		2
S			2
			1
			1

Item No.	Pic.		Qty.
AA		3*3M	72+2
		3*4M	100+2
BB		M6X12	16+1
CC		ST3. 9*16	2+1
DD		M10X100	16+1
EE		M4X13	12+1
KK			4

Warning


During the snowy season or when snow is forecast, turn the louvers to vertical to avoid damaging the pergola.

Installation Tools




Attention! ! !


Before installation, you need to carefully check the position of each parts shown on this page to avoid mis-installation and rework!



1




BB




M6X16

16


2












3




4



5



6







KK






X4


7



M14




DD



M10X100

16


S




14-17

X1

8



AA



M6X12



3*3M

72



3*4M

100


9



10




EE



M4*13

12

11




N



M4 × 10

1

CC



ST3.9 × 16

2